

 Blueair

# User manual



SCAN FOR SUPPORT

Air Purifier  
Blue Signature

# Table of Contents

EN

**Please read this user manual carefully and keep it for future reference.**

The latest version of this user manual can be found on [www.blueair.com](http://www.blueair.com).

## Table of Contents

Safety information	3
Blue Signature air purifier	5
Product map	6
Device controls	7
Display information	9
Getting started	10
Filter replacement information	12
Maintenance information	15
Accessories – Sold separately	16
Moving the device	17
Troubleshooting	18
Disposal, Support, and Warranty	19
Regulatory information	20



# Safety Information

Blue Signature air purifier is an electrical appliance for indoor use only. Take the necessary precautions to reduce the risk of fire, electric shock or injury.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Supervise children to ensure that they do not play with the appliance.
- Cleaning and product maintenance should not be conducted by children.
- Always disconnect the appliance from the power supply before maintenance.
- If your Blueair appliance is found to be defective, we will replace it with the same or a similar model at no cost, per the warranty terms. Please use caution attempting repairs yourself, as this presents the danger of electrical shock or injury.
- Ensure that the power cable and the power plug are not at risk of getting damaged.
- If the appliance is damaged or malfunctions, turn it off, disconnect it from the power supply and contact Blueair.
- The power plug must be firmly inserted in the power socket.
- When disconnecting the unit from the power supply, do not pull on the power cord, pull on the power plug.
- Use the power cable provided with your Blueair air purifier to plug directly and firmly into an appropriate, electrical outlet.
- To reduce risk of fire, electric shock or injury to persons, do not use replacement parts that have not been recommended by manufacturer (e.g. parts made at home using a 3D printer).
- Do not use an extension cord or a power strip. Refer to the rating label on your appliance.
- Do not alter the power plug in any way. If the plug does not fit into the outlet, contact qualified personnel to install the proper outlet.

- To avoid risk of fire or electric shock, the appliance should only be used with the correct input voltage that it is rated for, refer to your rating label on the device.
- Do not use the included power cord for anything else but the appliance.
- Do not allow objects to enter or block the air inlets and air outlets as this can cause electric shock or damage the appliance.
- Do not sit on, stand, climb onto or hang from the appliance.
- Keep the appliance, including the power cable, at a safe distance from heated surfaces and open fire.
- Keep the appliance and power plug away from water and other liquids.
- Keep the appliance and power plug away from chemicals such as pesticides and deodorants.
- Always turn off and disconnect the appliance from the power supply before moving the unit, changing filters, cleaning or carrying out maintenance procedures.
- Never clean with gasoline, chemical solvents, or corrosive materials as these agents may damage the air purifier.
- Do not operate the device with a damaged cord or plug. Discard the device or return it to an authorized service facility for examination and/or repair.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- The energy efficiency of an ENERGY STAR certified model is measured based on a ratio between the model's CADR for Smoke and the electrical energy it consumes, or CADR/Watt.
- This product complies with the maximum allowable concentration of ozone of 0.050 parts per million by volume (ppmv) in a 24-hour period.

**WARNING: RISK OF ELECTRIC SHOCK** – These servicing instructions are for use by qualified personnel only. To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.

# Blue Signature air purifier

## Product introduction



Blue Signature is an advanced air purifier with built-in sensors, a control display showing indoor pollution level for PM2.5 (PM 1 and PM 10 in the Blueair app). To adjust the settings of your product, you can either use the control panel on the device or the Blueair app, which unlocks additional features and functions.

## Recommendations for best performance

- Ensure that the size of the room where the air purifier is placed does not exceed the recommended capacity.
- Position the air purifier in an area where air can freely flow in and out, ensuring proper circulation.
- Maintain a distance of at least 4 inches (10 cm) between the air purifier and any other object to ensure proper air circulation.
- Keep the doors and windows closed while the air purifier is in operation.
- Replace the filter when the filter replacement indicator turns red on the control panel.
- Refer to the maintenance instructions in this user manual for proper care.

# Product map

Product Name	Model	Model number
Blue Signature air purifier	SP4i	4312111000
		4312112000



- Ⓐ Table top surface
- Ⓑ Digital Display
- Ⓒ Control interface
- Ⓓ Air quality indicator


- Ⓔ 360 degree Air Outlet
- Ⓕ Carry Handles
- Ⓖ Customizable pre-filter and air inlet
- Ⓗ Filter

- Ⓘ Wooden Legs Accessory  
(Sold separately)
- Ⓙ Chrome Disc Accessory  
(Sold separately)

# Device Controls

## Wave to wake up

The display is awoken by motion detected near the device. Wave your hand above the display and the control and display panel will illuminate.



### On/Standby Button

Turn the device on or go into Standby mode.



### Fan Speed

Press to change to desired fan speed from 0 to 4. Selected fan speed will be visible on the display.



### Auto Mode

In Auto mode, the device will automatically adjust the fan speed based on your indoor air PM2.5 levels to ensure optimal air quality.



### Night Mode

Turns the device to the lowest fan speed and lowest brightness.

# Device Controls



## Filter replacement

After replacing it with a new filter, always reset the Filter Replacement Indicator by pressing the Fan Speed button for 15 seconds or go to your device page in the Blueair App.



## Display lock button

Long press Display Lock Button for 2 seconds to activate/deactivate Lock mode. The lit indicator means the display is locked, preventing control panel operation.



## Reset Wi-Fi

If you choose not to connect the product, the Wi-Fi can be turned off. Long press the **Auto button for 15 seconds** and then release. The Wi-Fi will be turned off.

If you want to re-connect your air purifier, hold Auto button for 5 seconds until Wi-Fi LED starts blinking. Then follow the instructions in the “Connect to the Blueair App” section.

**PM2.5**

## Display indicators


Display your room's PM2.5 pollution level on the interface.



## Factory reset

Reset the device to the factory setting by pushing the On/Standby button for 15 seconds.

# Display Information



First time start up will display calibration animation while your purifier is analyzing your indoor air quality.



Air purifier will display the number of minutes until air will be clean. This number of minutes will go down until 0, which will indicate the air is now clean.



When the air is clean a check mark (✓) will be displayed with text "Air is clean".



Number on display indicates current air quality as PM2.5 values. PM2.5 are fine particles that can be inhaled such as dust, soot, dirt, and smoke commonly found in the home.



When you adjust fan speed or mode your selection will be displayed on the interface (Auto, Fan Speed or Eco).



Indicates that Night Mode is active and the lights of the User Interface and Air Quality Indicator will then dim down.



Indicates if the purifier is ready for Wi-Fi connection.



AirSense mode automatically refreshes your air few times per day. This mode can be turned off or on in the Blueair app.

# Getting started

## Connect to the Bluair App

Connecting to the Blueair App allows you to control the air purifier remotely and monitor filter usage. The app offers additional features to the device.

### Step 1

Download the Blueair App from the App Store or Google Play.

### Step 2

Open the app. Create or sign into your Blueair account.

### Step 3

Click on + Add device and follow the instructions in the app

## First time connection tips

Turn on your air purifier. Press and hold the Auto button for 5 seconds to prepare the air purifier for pairing. Once the Wi-Fi indicator is visible on the display and blinking, it is ready to be paired with your app.



Bluetooth is required for first time pairing. Turn your phone's bluetooth on and keep your phone within 3 feet (1 meter) of the air purifier for initial pairing.



Keep your air purifier within 15 feet (4.5 meters) of your Wi-Fi router when connecting the product for the first time.



Make sure you are using a visible Wi-Fi network. VPN (Virtual Private Network) should be deactivated while using the Blueair app.





This air purifier can only connect to a 2.4 GHz Wi-Fi network. If you are using a dual-band Wi-Fi router, make sure to select 2.4GHz.



## Air Quality Indicator

Blue Signature air purifier has a sensor to measure the fine particle levels (PM1, PM2.5, PM10) in the room. The AQI indicator displays the air quality status in five colors, from excellent (blue) to very polluted (dark orange).



The purifier is designed to serve as a table top, so you can place items like books, phone, decorations.

### **However, do not place any of the below items on top of the appliance:**

- Wet items or liquid
- Heavier than 11 lbs (5kg)
- Hot items directly or items that heat up
- Chemical items



# Filter replacement information

## Changing the filter

**Important!** Always turn off and disconnect the appliance from the power supply before changing filters, cleaning, or carrying out device maintenance procedures.

The air purifier uses Blueair's proprietary RealTrack algorithm to calculate the remaining lifetime of the filter based on actual usage and indoor pollution levels. When it is time to change the filter, the filter replacement indicator will appear red on the control panel on top of the device. The recommended time for filter change is 9 - 12 months.



Easily order Blueair filters from [www.blueair.com](http://www.blueair.com) or sign up to Blueair filter subscription for additional discount.

## Changing the filter


### Step 1

Turn off the air purifier and unplug it. Remove the pre-filter fabric.




### Step 2

Unlock the current filter by pulling open the connector.



### Step 3

Wrap the new filter around the purifier body and connect it. Ensure the correct side is facing up, as indicated by the arrow on the filter.




### Step 4

Pull back on the prefilter fabric. Turn the purifier back on.



### Step 5

Reset the Filter Indicator by pressing the Fan Speed button for 15 seconds or go to your device page in the Blueair App<sup>®</sup>



## Cleaning your washable pre-filter

Clean your pre-filter regularly when you see dust or dirt. Vacuum the exterior of the fabric with a soft brush attachment. For a deeper cleanse wash according to the pre-filter maintenance instructions and hang to dry.

### Step 1

Turn the air purifier off and unplug it.



### Step 2

Remove the fabric pre-filter.



### Step 3

Wash according to instructions on the fabric pre-filter's label.



### Step 4

Pull the clean pre-filter back over the main filter.



### Step 5

Please ensure that the logo tag of the pre-filter is on the upper part.



# Maintenance Information

To maintain optimal air purification performance regular maintenance is recommended. Please follow below recommended steps to clean your device.

## General

- Disconnect the air purifier from the power supply.
- Do not allow foreign objects to enter the air inlets or air outlets. This may cause electric shock or damage the air purifier.
- Never clean with gasoline, chemical solvents or corrosive materials as these agents may damage the air purifier.
- Do not wash the replacement filter, it's not washable or reusable.

## Cleaning


- Wipe the top of the air purifier with a soft, clean cloth.
- Clean and check the power cable and power plug for wear or damages.
- Clean the pre-filters by washing in the washing machine or vacuum on low setting with a soft brush attachment (not included).

# Accessories – Sold Separately


ACCESSORIES ARE PURCHASED SEPARATELY.

## Available options:

One set of wooden feet



One chrome disc



# Moving the device

**Important!** Unplug the air purifier before moving it.

The air purifier has recess handle making it easier to move.

Grab the recessed handles on both sides, lift and move the product to the desired location.



# Troubleshooting

Issue	Potential Cause	Try This
There is a red hatch icon on my air purifier's panel.	It is time to change the filter.	1. Change filter according to the instructions in this guide. 2. Reset the Filter Indicator by pressing the Fan Speed button for 15 seconds or go to your device page in the Blueair App.
My air purifier is making too much noise.	Air purifiers that are set on a high-speed level produce more noise because they function at faster rates.	Set a lower fan speed or reset Filter indicator via the app. Adjust to a lower fan speed to reduce noise level.
	If the filter is too dirty and clogged the air purifier will not get sufficient airflow which may result in increased noise levels.	Replace the filter when the Filter replacement indicator turns red.
I cannot connect my air purifier.	The air purifier is too far from your phone and router during the setup.	1. Ensure that your phone, air purifier and Wi-Fi router are in the same room and in close distance during initial set up, within 15 feet (4.5 meter). Once you have successfully paired your air purifier you can place it at your desired location. 2. Make sure that your air purifier is plugged in and powered on.
	The Blueair App is not up to date.	Download the latest Blueair app version from the App store.
	The router is not on or has no connection. The router is not using a standard connection.	Ensure the following before trying to connect your product: 1. Internet is currently running 2. You are using a 2.4GHz network. 3. Deactivate VPN.
	Bluetooth is deactivated.	Ensure Bluetooth is enabled on your phone.
My air purifier has lost connection.	Temporary Wi-Fi disturbances. New Wi-Fi settings or router.	If your air purifier does not re-connect by itself after a few minutes: 1. Open the Blueair app. 2. Select your air purifier and go to Device settings. 3. Delete the air purifier. 4. Go back to the home screen, click on the "+" sign in the upper right corner and choose "Add device". Follow the connection instructions.
My indoor air quality is not improving.	Indoor air quality remains polluted. Air quality sensors are dusty and showing incorrect levels.	1. Unplug the air purifier and wait for approximately 30 seconds. 2. Reconnect the power cable. 3. Press the On/Standy button. If the air quality does not improve with the use of the air purifier and ventilation, please contact us at <a href="http://www.blueair.com">www.blueair.com</a> .

For more information and troubleshooting tips, please check the Support page on [www.blueair.com/support](http://www.blueair.com/support).

# Disposal, support and warranty

## Disposal and recycling

The air purifier should be disposed or recycled as electrical waste and the filter should be disposed as regular waste. If you have questions regarding the disposal and recycling of your device, please contact your local recycling facility.

## Help and support

If you have questions about your product, please visit [www.blueair.com](http://www.blueair.com) or contact your local Blueair retailer.

## Limited warranty information

The air purifier has a limited warranty of 3 years (1 year standard warranty and 2 extra years upon registration).



# Regulatory information

**WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note!** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

This Class B digital apparatus complies with Canadian ICES-003.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

FCC/ISED RF Exposure Information: This equipment should be installed and operated with a minimum distance of 8 inches (20 cm) between the unit and your body.

# Table des matières

FR

**Veuillez lire attentivement ce manuel d'utilisation et le conserver pour référence future.**

La dernière version de ce manuel d'utilisation est disponible sur [www.blueair.com](http://www.blueair.com).

## Table des matières

Informations de sécurité	22
Purificateur d'air Blue Signature	24
Carte des produits	25
Contrôles des appareils	26
Afficher les informations	28
Mise en route	29
Informations sur le remplacement du filtre	31
Informations d'entretien	34
Accessoires - Vendus séparément	35
Déplacer l'appareil	36
Dépannage	37
Mise au rebut, assistance et garantie	38
Informations réglementaires	39

# Informations de sécurité

Le purificateur d'air Blue Signature est un appareil électrique destiné à un usage intérieur uniquement. Prenez les précautions nécessaires pour réduire le risque d'incendie, de choc électrique ou de blessure.

- Cet appareil peut être utilisé par des enfants âgés de 8 ans et plus ainsi que par des personnes ayant des capacités physiques, sensorielles ou mentales réduites, ou manquant d'expérience et de connaissances, à condition qu'elles aient reçu une surveillance ou des instructions concernant l'utilisation de l'appareil de manière sécurisée et qu'elles comprennent les dangers associés.
- Surveillez les enfants pour vous assurer qu'ils ne jouent pas avec l'appareil.
- Le nettoyage et l'entretien du produit ne doivent pas être effectués par des enfants.
- Débranchez toujours l'appareil de l'alimentation électrique avant l'entretien.
- Si votre appareil Blueair s'avère défectueux, nous le remplacerons gratuitement par un modèle identique ou similaire, conformément aux conditions de garantie. Veuillez faire preuve de prudence si vous tentez une réparation vous-même, car cela présente un risque de choc électrique ou de blessure.
- Assurez-vous que le câble d'alimentation et la fiche d'alimentation ne risquent pas d'être endommagés.
- Si l'appareil est endommagé ou fonctionne mal, éteignez-le, débranchez-le de l'alimentation électrique et contactez Blueair.
- La fiche d'alimentation doit être fermement insérée dans la prise de courant.
- Lorsque vous débranchez l'appareil de l'alimentation électrique, ne tirez pas sur le cordon d'alimentation, mais sur la fiche d'alimentation.
- Utilisez le câble d'alimentation fourni avec votre purificateur d'air Blueair pour le brancher directement et solidement dans une prise électrique appropriée.
- Pour réduire les risques d'incendie, de choc électrique ou de blessures corporelles, n'utilisez pas de pièces de rechange qui n'ont pas été recommandées par le fabricant (par exemple, des pièces fabriquées à la maison à l'aide d'une imprimante 3D).
- N'utilisez pas de rallonge ou de multiprise. Reportez-vous à l'étiquette signalétique de votre appareil.

- Ne modifiez en aucun cas la fiche d'alimentation. Si la fiche ne rentre pas dans la prise, contactez un personnel qualifié pour installer la prise appropriée.
- N'utilisez pas le cordon d'alimentation fourni pour autre chose que l'appareil.
- Ne laissez pas d'objets pénétrer ou bloquer les entrées et sorties d'air car cela pourrait provoquer un choc électrique ou endommager l'appareil.
- Ne vous asseyez pas, ne vous tenez pas debout, ne grimpez pas sur l'appareil et ne vous y suspendez pas.
- Gardez l'appareil, y compris le câble d'alimentation, à une distance sûre des surfaces chauffées et du feu ouvert.
- Gardez l'appareil et la fiche d'alimentation à l'écart de l'eau et d'autres liquides.
- Gardez l'appareil et la fiche d'alimentation à l'écart des produits chimiques tels que les pesticides et les déodorants.
- Éteignez toujours et débranchez l'appareil de l'alimentation électrique avant de le déplacer, de changer les filtres, de le nettoyer ou d'effectuer des opérations d'entretien.
- Ne nettoyez jamais avec de l'essence, des solvants chimiques ou des matériaux corrosifs car ces agents pourraient endommager le purificateur d'air.
- N'utilisez pas l'appareil avec un cordon ou une fiche endommagée. Jetez l'appareil ou retournez-le à un centre de service agréé pour examen et/ou réparation.
- Si le cordon d'alimentation est endommagé, il doit être remplacé par le fabricant, son agent de service ou des personnes qualifiées similaires afin d'éviter tout danger.
- Ce produit est conforme à la concentration maximale autorisée d'ozone, fixée à 0,050 partie par million en volume (ppmv) sur une période de 24 heures.

**AVERTISSEMENT : RISQUE DE CHOC ÉLECTRIQUE.** Ces instructions d'entretien sont réservées à un personnel qualifié. Pour réduire le risque de choc électrique, n'effectuez que les opérations décrites dans le mode d'emploi, sauf si vous êtes qualifié pour en effectuer d'autres. Pour éviter tout risque d'incendie ou de choc électrique, l'appareil ne doit être utilisé qu'avec la tension d'entrée correcte pour laquelle il est conçu, reportez-vous à l'étiquette signalétique de l'appareil.

# Purificateur d'air Blue Signature

## Présentation du produit



Blue Signature est un purificateur d'air avancé doté d'un écran de contrôle, de capteurs intégrés et d'un affichage indiquant le niveau de pollution intérieure pour les PM2.5 (PM1 et PM10 dans l'application Blueair). Pour ajuster les paramètres de votre produit, utilisez soit le panneau de commande de l'appareil, soit l'application Blueair, qui donne accès à des fonctionnalités supplémentaires.

## Recommandations pour de meilleures performances

- Assurez-vous que la taille de la pièce où est placé le purificateur d'air ne dépasse pas la capacité recommandée.
- Placez le purificateur d'air dans une zone où l'air peut entrer et sortir librement, assurant une bonne circulation.
- Maintenez une distance d'au moins 4 pouces (10 cm) entre le purificateur d'air et tout autre objet pour assurer une bonne circulation de l'air.
- Gardez les portes et les fenêtres fermées pendant que le purificateur d'air est en fonctionnement.
- Remplacez le filtre lorsque l'indicateur de remplacement du filtre devient rouge sur le panneau de commande.
- Reportez-vous aux instructions d'entretien de ce manuel d'utilisation pour un entretien approprié.

# Carte des produits

Nom du produit	Modèle	Numéro de modèle
Purificateur d'air Blue Signature	SP4i	4312111000
		4312112000




- Ⓐ Surface du plateau
- Ⓑ Affichage numérique
- Ⓒ Interface de contrôle
- Ⓓ Indicateur de la qualité de l'air
- Ⓔ Sortie d'air à 360 degrés
- Ⓕ Poignées de transport
- Ⓖ Pré-filtre et entrée d'air personnalisables
- Ⓗ Filtre
- Ⓘ Accessoire : pieds en bois (vendus séparément)
- Ⓙ Disque Chrome (vendu séparément)

# Contrôles des appareils

## Réveil par geste

L'écran s'active lorsqu'un mouvement est détecté près de l'appareil. Faites un geste de la main au-dessus de l'écran et le panneau de contrôle et d'affichage s'illuminera.



### Bouton marche/veille

Allumez l'appareil ou passez en mode veille.



### Vitesse du ventilateur

Appuyez pour passer à la vitesse du ventilateur souhaitée de 0 à 4. La vitesse de ventilateur sélectionnée sera visible sur l'écran.



### Mode automatique

En mode Auto, l'appareil ajustera automatiquement la vitesse du ventilateur en fonction des niveaux de PM2.5 de votre air intérieur pour garantir une qualité d'air optimale.



### Mode nuit

Fait tourner l'appareil à la vitesse de ventilateur la plus basse et à la luminosité la plus basse.

# Contrôles des appareils



## Remplacement du filtre

Après avoir remplacé le filtre par un nouveau, réinitialisez toujours l'indicateur de remplacement du filtre en appuyant sur le bouton de vitesse du ventilateur pendant 15 secondes ou en allant sur la page de votre appareil dans l'application Blueair.



## Réinitialiser le Wi-Fi

Si vous choisissez de ne pas connecter le produit, le Wi-Fi peut être désactivé. Appuyez longuement sur le bouton Auto pendant 15 secondes, puis relâchez. Le Wi-Fi sera désactivé.

Si vous souhaitez reconnecter votre purificateur d'air, maintenez le bouton Auto enfoncé pendant 5 secondes jusqu'à ce que le voyant Wi-Fi commence à clignoter. Suivez ensuite les instructions de la section "Se connecter à l'application Blueair".



## Bouton de verrouillage de l'affichage

Appuyez longuement sur le bouton de verrouillage de l'écran pendant 2 secondes pour activer/désactiver le mode de verrouillage. Le voyant allumé signifie que l'écran est verrouillé, empêchant le fonctionnement du panneau de commande.

## PM2.5

## Indicateurs d'affichage


Affichez le niveau de pollution PM2.5 de votre pièce sur l'interface.



## Réinitialisation d'usine


Réinitialisez l'appareil aux paramètres d'usine en appuyant sur le bouton Marche/Veille pendant 15 secondes.

# Afficher les informations


- 
- Le premier démarrage affichera une animation d'étalement pendant que votre purificateur analyse la qualité de votre air intérieur.
- 
- Le purificateur d'air affichera le nombre de minutes restantes avant que l'air ne soit purifié. Ce nombre diminuera progressivement jusqu'à 0, indiquant que l'air est désormais propre.
- 
- Lorsque l'air est propre, une coche s'affiche avec le texte "L'air est propre".
- 
- Le nombre affiché indique la qualité actuelle de l'air sous forme de valeurs PM2.5. Les PM2.5 sont de fines particules qui peuvent être inhalées, telles que la poussière, la suie, la saleté et la fumée que l'on trouve couramment dans la maison.
- 
- Lorsque vous réglez la vitesse ou le mode du ventilateur, votre sélection sera affichée sur l'interface.
- 
- Indique que le mode nuit est actif et les lumières de l'interface utilisateur et de l'indicateur de qualité de l'air s'atténueront alors.
- 
- Indique si le purificateur est prêt pour la connexion Wi-Fi.
- 
- Le mode AirSense rafraîchit automatiquement votre air deux fois par jour. Ce mode peut être activé ou désactivé dans l'application Blueair.

## Indicateur de la qualité de l'air

Le purificateur d'air Blue Signature dispose d'un capteur pour mesurer les niveaux de particules fines (PM1, PM2.5, PM10) dans la pièce. L'indicateur AQI affiche l'état de la qualité de l'air en cinq couleurs, d'excellent (bleu) à très pollué (orange foncé).



Indicateur de la qualité de l'air



Le purificateur est conçu pour servir de surface de table, vous pouvez donc y poser des objets comme des livres, un téléphone ou des décorations.

**Cependant, ne placez aucun des objets ci-dessous sur l'appareil:**

- Objets mouillés ou liquide
- Plus lourd que 11 lb (5 kg)
- Articles chauds directement ou articles qui chauffent
- Articles chimiques



# Informations sur le remplacement du filtre

## Changer le filtre

**Important!** Éteignez et débranchez toujours l'appareil de l'alimentation électrique avant de changer les filtres, de le nettoyer ou d'effectuer des procédures de maintenance de l'appareil.

Le purificateur d'air utilise l'algorithme RealTrack exclusif de Blueair pour calculer la durée de vie restante du filtre en fonction de l'utilisation réelle et des niveaux de pollution intérieure. Lorsqu'il est temps de changer le filtre, l'indicateur de remplacement du filtre apparaîtra en rouge sur le panneau de commande situé au-dessus de l'appareil. Le délai recommandé pour le changement du filtre est de 9 à 12 mois.

Commandez facilement des filtres Blueair sur [www.blueair.com](http://www.blueair.com) ou abonnez-vous pour bénéficier de réductions supplémentaires.



Indicateur de  
remplacement  
du filtre

## Changer le filtre


### Étape 1

Éteignez le purificateur d'air et débranchez-le. Retirez le tissu pré-filtrant.




### Étape 2

Déverrouillez le filtre actuel en ouvrant le connecteur.



### Étape 3

Enroulez le nouveau filtre autour du corps du purificateur et connectez-le.



Assurez-vous que le bon côté est orienté vers le haut, comme indiqué par la flèche sur le filtre.

### Étape 4

Tirez sur le tissu pré-filtrant. Rallumez le purificateur.



### Étape 5

Réinitialisez l'indicateur de filtre en appuyant sur le bouton de vitesse du ventilateur pendant 15 secondes ou allez sur la page de votre appareil dans l'application Blueair.



# Informations d'entretien

Pour maintenir des performances optimales de purification de l'air, un entretien régulier est recommandé. Veuillez suivre les étapes recommandées ci-dessous pour nettoyer votre appareil.

## Général

- Débranchez le purificateur d'air de l'alimentation électrique.
- Ne laissez pas d'objets étrangers pénétrer dans les entrées ou les sorties d'air. Cela pourrait provoquer un choc électrique ou endommager le purificateur d'air.
- Ne nettoyez jamais avec de l'essence, des solvants chimiques ou des matériaux corrosifs car ces agents pourraient endommager le purificateur d'air.
- Ne lavez pas le filtre de remplacement, il n'est ni lavable ni réutilisable.

## Nettoyage


- Essuyez le dessus du purificateur d'air avec un chiffon doux et propre.
- Nettoyez et vérifiez l'état du câble et de la fiche d'alimentation afin de détecter toute usure ou tout dommage.
- Nettoyez les préfiltres en les lavant à la machine à laver ou en les aspirant à basse température avec une brosse douce (non incluse).

# Déplacer l'appareil

**Important!** Débranchez le purificateur d'air avant de le déplacer.

Le purificateur d'air est doté d'une poignée encastrée facilitant son déplacement.

Saisissez les poignées encastrées des deux côtés, soulevez et déplacez le produit à l'emplacement souhaité.



# Dépannage

<b>Problème</b>	<b>Cause potentielle</b>	<b>Essayez ceci</b>
Il y a une icône rouge en forme de trappe sur le panneau de mon purificateur d'air.	Il est temps de changer le filtre.	1. Changez le filtre conformément aux instructions de ce guide. 2. Réinitialisez l'indicateur de filtre en appuyant sur le bouton de vitesse du ventilateur pendant 15 secondes ou allez sur la page de votre appareil dans l'application Blueair.
Mon purificateur d'air fait trop de bruit.	Les purificateurs d'air réglés à une vitesse élevée produisent plus de bruit car ils fonctionnent à des rythmes plus rapides.  Si le filtre est trop sale et obstrué, le purificateur d'air ne recevra pas un débit d'air suffisant, ce qui peut entraîner une augmentation des niveaux de bruit.	Réglez une vitesse de ventilateur inférieure. Ajustez à une vitesse de ventilateur inférieure pour réduire le niveau de bruit.  Remplacez le filtre lorsque l'indicateur de remplacement du filtre devient rouge.
Je n'arrive pas à connecter mon purificateur d'air.	Le purificateur d'air est trop éloigné de votre téléphone et de votre routeur lors de la configuration.  L'application Blueair n'est pas à jour.	1. Assurez-vous que votre téléphone, votre purificateur d'air et votre routeur Wi-Fi se trouvent dans la même pièce et à proximité lors de la configuration initiale, à moins de 15 pieds (4,5 mètres). Une fois que vous avez couplé avec succès votre purificateur d'air, vous pouvez le placer à l'emplacement souhaité. 2. Assurez-vous que votre purificateur d'air est branché et allumé.  Téléchargez la dernière version de l'application Blueair depuis l'App Store.
Mon purificateur d'air a perdu la connexion.	Perturbations temporaires du Wi-Fi. Nouveaux paramètres Wi-Fi ou routeur.  Le Bluetooth est désactivé.	Assurez-vous de ce qui suit avant d'essayer de connecter votre produit : 1. Internet fonctionne actuellement. 2. Vous utilisez un réseau 2,4 GHz. 3. Désactivez le VPN.  Assurez-vous que Bluetooth est activé sur votre téléphone.
La qualité de mon air intérieur ne s'améliore pas.	La qualité de l'air intérieur reste polluée. Les capteurs de qualité de l'air sont poussiéreux et affichent des niveaux incorrects.	Si votre purificateur d'air ne se reconnecte pas tout seul après quelques minutes : 1. Ouvrez l'application Blueair. 2. Sélectionnez votre purificateur d'air et accédez aux paramètres de l'appareil. 3. Supprimez le purificateur d'air. 4. Revenez à l'écran d'accueil, cliquez sur le signe "+" dans le coin supérieur droit et choisissez "Ajouter un appareil". Suivez les instructions de connexion.
		1. Débranchez le purificateur d'air et attendez environ 30 secondes. 2. Rebranchez le câble d'alimentation. 3. Appuyez sur le bouton Marche/Veille. Si la qualité de l'air ne s'améliore pas avec l'utilisation du purificateur d'air et de la ventilation, veuillez consulter la page d'assistance sur <a href="http://www.blueair.com/support">www.blueair.com/support</a> .

Pour plus d'informations et des conseils de dépannage, veuillez consulter la page d'assistance sur [www.blueair.com/support](http://www.blueair.com/support).

# Mise au rebut, assistance et garantie

## Élimination et recyclage

Le purificateur d'air doit être éliminé ou recyclé comme déchet électrique et le filtre doit être éliminé comme déchet ordinaire. Si vous avez des questions concernant l'élimination et le recyclage de votre appareil, veuillez contacter votre centre de recyclage local.

## Aide et support

Si vous avez des questions sur votre produit, veuillez visiter [www.blueair.com](http://www.blueair.com) ou contacter votre détaillant Blueair local.

## Informations sur la garantie limitée

Le purificateur d'air est couvert par une garantie limitée de 3 ans (1 an de garantie standard et 2 années supplémentaires après enregistrement).





[www.blueair.com](http://www.blueair.com)

Blueair Inc.  
125 S Clark,  
Suite 2000,  
Chicago, IL, 60603 USA